

EASY TO INSTALLATION



Clean the surface.



Peel off the self adhesive pad cover.



Stick the holder to the wall and press firmly for more than 30 seconds.



Rest it for more than 24 hours before hanging anything.