

# Prepare ground base



- ❖ First of all, calculate how much grass you will need.
- ❖ Make sure that the surface to be covered is clean and smooth ready to receive the artificial grass.  
(Compact and level the ground)

# Lay down artificial grass



- ❖ Lay the artificial grass on to the clean and level area.
- ❖ Allow approximately 50mm of artificial grass to trim off to make that perfect edge is in doorways or up a wall. Leave for around 2 to 3 hours to settle. This helps stop any wrinkling or creasing.



# Cut grass edges



- ❖ Cut and trim artificial grass, using a sharp knife making sure there aren't gaps between walls and grass.
- ❖ Then lift two edges to lay the seeming tapes.



# Lay down seaming tapes



- ❖ Lay down seaming tapes and make sure the joint is in the middle of seaming tapes
- ❖ Make the joins using the correct type of straps and glue - only quality outdoor tape and glue (water proof) should be used.





# Glue the joints



Spreading the glue onto both seaming tape and artificial grass backing.

- ❖ Leave for sometime to allow the glue to become dry. (the time please refer to the instruction of glue)
- ❖ Carefully put two edges down and press them. Make sure the joints look natural.

# Infill



Depends. Outdoor use can be filled in fine sands to make the grass heavy and protect grass from being blown away.

- ❖ Rake and spread the infill evenly, taking care not to over fill the surface.
- ❖ Combing surface to make sure sands go down to grass ends.



❖ Kind note:

1. Fine sands can better protect body.
2. Except customer request, most of time, landscape grass doesn't need filling in sands for either outdoor or indoor use.



# Fix edges



- ❖ Use wooden nails/ landscaping nails to fix the edges next to walls or other kinds of edges.
- ❖ Distance, every 50mm or so.
- ❖ Indoor project doesn't need nail, but just seaming tapes and glue.



**Congratulation! Enjoy time!**

