

ASSEMBLY INSTRUCTION

- STEP1 INSERT TUBE A INTO TUBE B
- STEP2 THEN TIGHTEN TUBE B WITH TUBE C
- STEP3 PUT TUBE C INTO THE HOLE OF BASE D
TIGHTEN THEN TOGETHER THEM WITH
WASHER E AND NUT F

