




Open the mainframe and lock the lever If you find the frame is unsteady, please tighten the screw













1. Insert the rear wheels into the mainframe and make sure the holes are aligned 2.Insert the screw (a) into the hole and secure the "star bolt"





LIFTING LEVER INSTALLATION

1.Insert the lifting lever into the mainframe

2.Adjusting the suitable height, then make sure the holes are aligned

3.Insert the star bolt[®] into the hole and tighten it

4.Attach the Card buckle to the lifting rod











1. Insert the knee pad into the tube

2.Adjusting the suitable height, then make sure the holes are aligned 3. Insert the screw (A) into the hole and secure the star bolt





Make sure the holes are aligned, then insert the screw[©] into the hole and secure the nut with a tool,





