

Coffee Table





Width-51.18inch Depth-19.69inch Height-17.72inch


Note:No. 1 2 board with protective film.Please tear it off after installation!





Hardware installation example \prod This part cannot be separated, not included please install in strict Tool accordance with the assembly requirements \prod IV



















В

12PCS













В










В

4PCS






P.11


3.5*14 G1

4PCS


2PCS


D





LED light tape stick to the lower side of the board 1






NOTE: The battery in the remote control requires you to purchase and install it yourself. Model: CR2025 3. V Modell: CR2025 3.V


LED light

If you can't let the lights work successfully, please check the following:

- 1. Please check the direction of the connect, try it in the opposite direction, according to the following picture.
- 2. Please check the remote control, it need you to tear down the plastic septum before use it.
- 3. Don't let the remote control too far from the receiver, make sure there is no obstruction between them.
- 4. When using the remote control, please make sure to aim at the receiver, not the light strip



Remark: These two buttons are invalid because the product cannot adjust the brightness of the light.



Please note that for transportation safety, the remote control does not contain batteries; the attery model is: CR2025