
WF309200








PLEASE NOTE: The table top is covered with a tight plastic protective film.

If there are scratches on the product after disassembly, please don't worry, it's not product damage.

Please slowly tear off the protective plastic film on the surface along the edge. After peeling off, the product becomes smooth and clean.







philis head screwdrier rewuired of assembly (not include)



hammer (not include)



electric drill
(not include)

