

components - fittings

Please check you have all the panels listed below.

Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.


① x 1pc		② x 1pc	
			• • • • • • • • • • • • • • • • • • •
③ x 1pc	④ x 1pc	⑤ x 1pc	⑥ x 1pc
· · · · · · · · · · · · · · · · · · ·			
⑦ x 1pc	8 x 2pcs	⑨ x 1pc	10 x 1pc
• •			
11) x 1pc		12 x 2pcs	13 x1pc
			<u></u>
14) x 1pc	15 x 1pc	16 x 1pc	① x 4pcs
(18) x 4pcs	(19) x 4pcs	20 x 4pcs	


components - fittings

Please check you have all the panels listed below.


Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

			C
M6x35mm	Ф15х9mm	Ф8x30mm	M3x12mm
A x 48pcs	B x 48pcs	C x 20pcs	D x 32pcs
	M4x25mm		M4x12mm
E x 8pcs	F x 16pcs	G x 4pcs	H x 44pcs
Іх 1рс	J x 5pcs		







page 5 of 12




page 6 of 12







page 8 of 12




page 9 of 12






page 11 of 12



When the hinges are installed, you can refer to the pictures to adjust crevice of the doors till it's perfect:



- 1. To adjust the doors up and down, please refer to step (a)
- 2. To adjust the distance between the doors and side panels, please refer to step(b)
- 3. To adjust the gap between two doors, please refer to step (c)
- 4. After the adjustment finished, please tight the screws, refer to step (d)

