


Assembly Instructions

Item No.: 9318


Parts and hardware

A



1 piece of chair base

B




1 piece of backrest

C




2 pieces of backrest ears

Assembly System




- ❶ Take out the chair backrest(B) from chair base(A). Place the chair base(A) face down on a clean, non-marring surface.
- ❷ Connect the backrest plug(B) to the chair base plug(A).
- ❸ Connect backrest ears(C) to chair backrest(B). Make sure all parts are connected and securely locked into position.

Disassembly Instruction



- ❶ Take out backrest ears(C) from chair backrest(B).
- ❷ Open the flap on the backrest(B), use a screwdriver pressing outward on the metal ear on the preattached metal bracket on one side of the chair base(A).
- ❸ Keep the chair base(A) in place, pull the backrest(B) upward at the same time, repeat the same step for another side.

Warning



- Do not allow children to play on the recliner.
- Always leave the recliner in an upright and closed position after use.
- Keep hands and feet clear of the footrest mechanism and any gaps.
- Don't sit on the armrests of the recliner.

User Instructions

To get into the recline position:

- The body weight against the backrest, press your hands on the armrest and push forward
- Let the plank stretch out
- Push forward with your legs on the pedals
- The chair will be stretches out to 160°



Enjoy your most comfortable time



110°



120°



135°




150°













160°

To move the chair back into the upright :

- Tilt your body weight slightly forward and upwards.
- The backrest will come up to an upright position.
- Use your feet to push the footrest down.
- The chair will automatically lock when it is in the fully upright position.
- Where necessary, use your arms help lift/push yourself out of the seat



Care & Maintenance

	●Do not put hot items directly on furniture surface
	●Do not clean furniture with harsh cleansers or polish
	●Do not place furniture under direct sunlight
	●Do not place furniture near heating or cooling vents
	●Do not write on furniture without a padded barrier to protect the surface
	●For indoor use only
	●For residential use only
	●Stains may be removed with mild soap solution and damp cloth
	●Children should not climb or jump on the furniture
	●Dust and pick-up spills using a clean, non-colored, lint-free cloth