





ASSEMBLY INSRTRUCTION

WF304266










① x 1	② x 1	③ x 1	④ x 1
⑤ x 1	⑥ x 1	⑦ x 1	⑧ x 2
⑨ x 1			









A x20+2	B x22+2	C x22+2	Φ3x14mm D x15+2	E x3
F x1	G x1	H x1	I x12+1	J x12+1
K x1	Φ4x12mm L x1	Φ4x35mm M x1	N x1	





step 1





step 2





step 3





step 4





step 5






step 6







step 7





step 8







step 9



step 10



step 11



step 12

