User Manual

AW3218A1LR0

info@hausinluckgroup.com

Warranty

This product has been manufactured and inspected to the highest possible quality standards. Our sinks carry a limited 5 years warranty for residential use.

Should you experience any defects in materials or workmanship within the warranty period, we will repair or replace the defective product, subject to the following conditions:

• Any claim made under this warranty must include a copy of a valid proof of purchase showing the date and place of purchase.

• Our obligation under this warranty is to the original purchaser only, and may not be transferred.

• Product replacement does not include shipping costs or labor installation costs.

• This warranty applies to residential installations only.

• We reserve the right to examine product in question and its installation prior to replacement.

• If an identical replacement product is not available, We reserve the right to replace the defective product with a similar product.

This warranty relates to defects in manufacture, materials or workmanship in a stainless steel kitchen sink supplied for installation into domestic premises in the United States. It does not extend to :

- Damage resulting from failure to maintain the product in accordance with the Care and Maintenance instructions in this manual.
- Normal wear and tear, scratches or accidental damage.
- Faults arising from improper use and/or installation.
- Defects in accessories, strainers and rinse grids.

All incidental or consequential damages are specifi- cally excluded. No additional warranties, express or implied are given, including but not limited to, any implied warranty of merchantability or fitness for a particular purpose.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Features

- 18 Gauge stainless steel
- Premium 304 grade stainless steel
- Heavy duty sound guard padding and undercoating
- Slanted bottom with elegant drain grooves for easy draining
- Zero radius corners for easy cleaning
- Drain placement Rear
- Lips on two sides to provide track for cutting board



Accessories (Included)

In the Box

- Cut out template
- Sink
- Mounting and installing brackets
- Accessories







Roll-up Drying Rack

Drying rack





Wood cutting board

Dimensions

Stainless steel grid Sink Strainer

Mode	Length	Width	Depth
AW3218A1LR0	32″	18″	9″





Prior to installation steps:

- 1. Unpack your new product and ensure that all the parts are contained in the packaging.
- 2. Keep the product in its original box until you are ready to install it.
- 3. The counter top must be flat.
- 4. Shut off the water supply if replacing a previously-installed vessel sink.
- 5. Observe all plumbing and building codes in your area.
- 6. It is recommended that installation of the product be done by a professional plumber.
- 7. We are not responsible for improper sink or countertop installation. We are not liable for any damages to sink or countertop or personal injury during installation.

Decide on your preference prior to installation.


Alignment of sink to cutout is critical for a superior fit and finished look. Depending on your aesthetic preference, sinks can be installed either with a 1/4" reveal, flush fit, or with a negative reveal. 1/4" reveal is recommended.

1/4" Reveal

The countertop edge sits approximately **1/4" back** from the edge of the sink and exposes the rim of the sink.


Flush Fit

The countertop meets the edge of the sink, **fitting flush** with the sink bowl.



1/4" Overhang

The countertop **extends 1/4**" over the edge of the sink on all sides.



Installation

1. Place template on countertop. Position it such that the sink will have proper clearance from cabinet.


2. Trace a line around the template. Determine what "reveal" you want your sink to have (see previous page) and based on that, adjust the line accordingly. Cut along the line. 3. Turn the countertop upside down, and mark evenly-spaced positions for the anchors for the mounting clip. We recommend 3 mounting clips for the sink sides 20" and longer, and 2 mounting clips for the shorter sides. Drill holes for the anchors (following the countertop manufacturer's instructions) as shown below. Use a drill bit with stop block to avoid drilling through the countertop. Secure anchors into the countertop and fasten mounting clips loosely. NOTE: For granite, marble or solid stone countertops we recommend using lead anchors which are glued to the countertop.

4. Clean the underside of the countertop and the rim of the sink. Using a good quality silicone caulk, apply silicone caulk evenly around the rim of the sink.

5. Place sink over the countertop opening. Tighten the screws until mounting clips are snug against sink.


6. Check alignment of sink to countertop opening and move slightly if you have to.

7. Tighten down clips evenly without overtightening. Remove excess silicone.



Strainer Installation Guide





Care and Maintenance

"The Do's"

1. When it comes to maintenance, the best thing you can do is be consistent in your cleaning. It is preferable to clean a little on a frequent basis than a heavy duty cleaning once in a while.

2. You should make sure that the sink is always clean and dry when not in use. This is the best method of preventative maintenance. Keep the sink water spot free and shiny by rinsing and towel drying after every use.

3. Keep the single clog free to prevent standing water which can lead to mineral deposit build up.

4. If a mineral build up should occur, use a mixture of vinegar and hot water to remove the deposit.

5. To clean your sink, use a non abrasive cleaning cloth combined with a mild cleaning procedure.

* Use a soft cloth and liquid detergent on a mirror finish deck.

- * Do Not Use Any Abrasive Materials On Sink Finish
- * For tougher stains use a mild abrasive cleaner like Ajax or Comet.

6. Wipe the sink dry after cleaning to discourage any water spotting.

7. Follow the direction of the grain when cleaning or scrubbing away stains. Scrubbing against the grain will show as a scratch.

"The Don'ts"

1. Avoid using any abrasive steel wood pads as they will leave an iron residue that will eventually lead to rust and corrosion.

2. Do not leave any steel or cast iron cookware in the sink for a long period of time. This may also leave iron particles that will corrode the sink

3. Do not leave any cleaning materials such as sponges or rags in the sink for an extended period of time.

Anything left in the sink can trap moisture which will eventually lead to staining 4. Avoid using any avrasive cleaning materials such as steel wool pads on the polished finish of the sink, this will lead to scratching.



PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE

Our friendly, specially trained,

technical support team will be happy to assist you with any concerns you may have regarding your