

















Assembly Instructions

W1673105925
W1673106107







<p>A</p>  <p>M4X8 x39</p>	<p>B</p>  <p>M5X8 x6</p>	<p>C</p>  <p>x12</p>	<p>D</p>  <p>x4</p>	<p>E</p>  <p>M4X20 x4</p>	<p>F</p>  <p>x2</p>
<p>G</p>  <p>x2</p>	<p>H</p>  <p>x2</p>	<p>I</p>  <p>x2</p>	<p>J</p>  <p>M5X50 x2</p>		




4






5







6




7



8



9



10

