


ASSEMBLY INSTRUCTIONS

ITEM NO: WF305859 & WF305858 & WF305857

DESCRIPTION: SECTIONAL



ASSEMBLY INSTRUCTIONS


ITEM NO: WF305859 & WF305858 & WF305857

DESCRIPTION: SECTIONAL

PARTS AND HARDWARE


Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.

A*1




Left Back Cushion

B*1




Left Console Back

C*2



Armless Back Cushion

D*2



Corner Back Cushion

E*1




Left Arm

F*1




Right Arm

G*1




Right Back Cushion

H*1




Left Seat Base

I*1



Wedge Seat Base

J*1



Right Seat Base

ASSEMBLY INSTRUCTIONS


ITEM NO: WF305859 & WF305858 & WF305857

DESCRIPTION: SECTIONAL


CAUTION: At least two adults are required to safely complete performing this task.
Other lifting attempts may risk back injury due to large and heavy part(s).




- 1 Carefully unpack and place parts on a clean flat surface.
- 2 Insert the female brackets at the Left Arm (E) onto the male brackets at the Left seat base (H), insert the female brackets at the Right Arm (F) onto the male brackets at the Right seat base (H), insert and push to the end, make sure the brackets are secured in position.



- 3 Attach the Left Seat Base (H) & Right Seat Base (J) to the Wedge Seat Base (I), ensuring it is correctly in place.



- 4 Attach the Backrests to the Seat Bases. Ensure it is correctly in place.



ASSEMBLY INSTRUCTIONS



ITEM NO: WF305859 & WF305858 & WF305857

DESCRIPTION: SECTIONAL

CAUTION: At least two adults are required to safely complete performing this task.
Other lifting attempts may risk back injury due to large and heavy part(s).



- 5** Stretch and pull down rear cover evenly before securing velcro strip to seat base. Repeat if necessary for better fit.



ASSEMBLY INSTRUCTIONS

ITEM NO: WF305859 & WF305858 & WF305857

DESCRIPTION: SECTIONAL

OPERATING YOUR UNIT

Converting to Footrest Position

- To raise or lower the legrest, push the power switch & hold.
- Release the switch when the legrest reaches the desired high

