Please make sure you've got everyting lists as following before assembly.

Q1: Missing parts when received.

A: If you find some parts are missing from the box, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions. We will send replacement to you asap.

Q2: Some parts damaged when arrived.

A: Please send clear photos about damaged part to us as attachment, we will check and offer you best solution soon.

Q3: The chair is stuck on reclining position, and no response when you press the reclining button.

A: Please kindly check if the power cord (C) are connected well with the motor. Sometimes the power cord (C) may fall off from the motor.


If the connection is good, then check the motor if it has some anomaly, like some noise comes out when you press the reclining button. If you can make sure the motor is defective, please contact us for replacement.



A Chair base




B Backrest






Power Recliner with Swivel and Rocker Assembly Instruction




How to remove the chair?


Please note that you need to take apart the backrest before.



STEP 1

Insert chair back to the chair base, make sure the on the back fully assembled to the bottom part.








NOTE:

No.1 wire connect the motor and the wire from rightside armrest, which use to connect the control panel.

No.2 wire connect the motor and power source (C).

Plug power cord and power source into outlet, then you can use all function.



How to enjoy the chair?

