


Outdoor Glider ASSEMBLY MANUAL



MODEL#: LYFT0524

Missing part? Damaged? Contact us via email at domiservice01@outlook.com

© Copyright 2022–2024 domi LLC. I All Rights Reserved.

Warnings and Cautions

Please retain this instruction for future usage and read carefully before assembly.

Make sure you have all the parts & hardware as item list shows.

2 adults are recommended to install your chair.

Do not discard any of the packaging until you have checked that you have all the parts and pack of fittings.


Check all bolts for tightness before use, and periodically check and tighten bolts ensure your chair works properly.


Some parts might have sharp edges/corners. Please follow basic safety precautions to reduce the risk of hurts.


CHOKE HAZARD


THIS ITEM CONTAINS SMALL PARTS WHICH CAN BE SWALLOWED BY CHILDREN.

PLEASE KEEP IT AWAY FROM CHILDREN UNDER 3
YEARS OLD and PETS DURING INSTALLATION.














Connect baseboard A and A3 using bolt 7, steel flat washer Z and nut 17.



















Attach steel and plastic triangle bracket together. Fix them on Aluminum base frame F with bolt 1 and steel flat washer V. $\widehat{G1}$ × 8PCS ▲ G1: Plastic triangle bracket \widehat{G} × 8PCS G: Steel triangle bracket.















Place the connecting rod roller 7 onto the base frame, then put the aluminum base frame on the top.










- (1) Install the table J onto the table legs H. Screw the table and fixing bar with steel flat washer V, bolt 2 and nut 17.
- (2) Connect the table with table legs with bolt 1 and steel flat washer V.






















13 4X

V10X

1712X × 12X

9 8X

22 2X





Fix the chair and chair frame with plastic pipe X, steel flat washer V, bolt 9&13 and nut 17.


▲ Plastic pipe X is between the chair and arm.

▲ Don't fully tighten the bolts!


Tighten the bolts on the chairs, then put the chairs onto the aluminum base frame.











- (1) Attach the rubber strip Y on the aluminum base frame E as shown.
- (2) Install chairs onto aluminum base frame.
- (3) Align the holes and tighten with steel flat washer V, bolt 10 and nut 17.

















(1) Insert roof support tube S into roof connect tube P. Align their holes and fix with steel flat washer V, bolt 3 and nut 17.


(2) Fix the roof support tube S and roof connect tube R with steel flat washer V and bolt 4.










Put the canopy onto the top as shown.








Press the plastic cap 20&21 on the steel nut 17.






(U1) 2X

Hang the netting U1 on the roof connect tube S.



Inspect and make sure all parts are connected. The outdoor glider is ready for use!



Warranty

Frames

Frames constructions are warranted to be free from defects in material and worksmanship for 1 year from item purchased. Damage to frame from negligence won't be covered by this warranty.

Cushions

Cushions are warranted to be free from defects in material and worksmanshipfor 1 year from item purchased. Damage from exposure to chemicals (including but not only oils, spills, fluids) won't be covered by this warranty.

Bolts & nuts

Bolts and nuts are warranted to be free from defects in material and worksmanship for 1 year from item purchased. Damage from exposure to chemicals (including not only oils, spills, fluids) won't be covered by this warranty.

Warranty Limitation

This warranty is for the original purchase order only. (Order numberrequired), This warranty is non-transferable." Domi Outdoor Living is responsible for the free replacement part including shipping charges for the 1 year warranty.

Warranty Exclusion

This warranty does not cover products subject to negligence, abuse usage,inappropriate installation. Domi Outdoor Living reserves the right to explain warranty exclusions. When there placement tem is applied, the 1 year warranty automatically expires. Please feel free to contact us for applying warranty.



RESOPT COMFORT IN YONR OWN BACKYARD

Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So if you have any questions about our product and assembly,please feel free to contact us. We will be here for you.

Support:





email:domiservice01@outlook.com

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.