



ASSEMBLY INSTRUCTION

HFSN-718

| | | |
|----------------|-----------------|----------------|
| Ax1 | Bx1 | |
| Cx2 | Dx1 | |
| Fx4 | Jx2 | Ex1 |
| Gx4 | Hx12 | ① |
| Lx1 | | |

