


ASSEMBLY INSTRUCTION

WAVE BED (USA) QUEEN/FULL WF313806/WF313807





Bed Parts are shipped inside a compartment in the back of the headboard & footboard.



NO	PART LIST		QTY	
A	Headboard		1 pc	
В	Headboard Leg		2 pcs	
С	Side Rail		4 pcs	
D	Footboard		1 pc	
Е	Center Support Rail		2 pcs	
F	Center Support Leg		4 pcs	
G	Bed Leg		2 pcs	
Н	Bed Slat		10 pcs	
I	Side Rail Support		2 pcs	
J	Slat Support		4 pcs	

NO	Н	ARDWARE LIST	QTY
1	JCBB M8 x 20mm		8 pcs
2	JCBC M6 x 60mm		4 pcs
3	JCBC M6 x 40mm		6 pcs
4	JCBC M6 x 25mm		8 pcs
5	Spring Washer M6		6 pcs
6	Flat Washer M6		14 pcs
7	Allen Key M4		1 pcs
8	Allen Key M5		1 pcs
9	Adjuster M6		4 pcs
10	CSK M4 x 20mm		6 pcs
11	CSK M4 x 30mm	<ammun (f)<="" td=""><td>20 pc</td></ammun>	20 pc
12	JCBB M6 x 30mm		12 pcs


NO		HARDWARE LIST	QTY
13	Adapter		1 pc
14	Remote		1 pc
15	LED light	800000	1 pc
16	Controller box		1 pc

Read this instruction carefully. Remove all wrapping material, staples and straps from the carton. See hardware and furniture part list for guidance. Be sure you have all wooden furniture parts on a clean and flat surface, such as carpet or rug, to prevent from being scratched.


CAUTION:

- 1. Do not Full Tighten the nut or screw until all ready to assemble.
- 2. Do not Over Tighten the nut or screw to avoid causing damages to the thread.
- 3. Keep all hardware part out reach of children.


















STEP 4

16		13	14	15
			00000	*******
	1 pc	1 pc	1 pc	1 pc



*Attach the velcro side of the LED light to the corresponding velcro tape under the slat support and footboard.

