

### WF322320 WF322321




### **ASSEMBLY INSTRUCTIONS**



## PARTS Check that you've received all parts listed below.

#### **BOX: 1/2** WF322320



03

# PARTS Check that you've received all parts listed below.


### BOX: 2/2 WF322321

(2) x 1	(3) x 1		
Side Board Left	Side Board Left		
(4) x 1	(9) x 1		
Foot Board	Support Slat		
04			

## HARDWARE Check that you've received all hardware listed below.

#### Hardware List

No.	OUTLOOK	DESC	QTY
A		<b>Bolts</b> 5/16"x50 mm	8
B		<b>Bolts</b> 5/16"x40 mm	2
(C)		<b>Bolts</b> 5/16"x30 mm	8
D		Plain washer Ø19x1.5 mm	18
E		Spring washer Ø13x1 mm	18
F		Allen key 80x30x4 mm	1
G	<b>Butterstations</b>	Screws Ø4x30 mm	20



STEP 3




D x 4



E x 4

F x 1





STEP 4



D x 4





E x 4



F x 1








### STEP 7





STEP 8



