ASSEMBLY INSTRUCTIONS


ROUND TABLE




WF296298


IMPORTANT NOTE:

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- (2) BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP




Part List For One	Hardware List For One
(A)	5/16" x 60mm
	BOLT (4PCS)
Table Top (1pc)	5/16" x 40mm
B	BOLT (4PCS)
	5/16" x 13mm
	SPRING WASHER (8PCS)
Legs (4pcs)	5/16" x 19mm
	FLAT WASHER (8PCS)
	5
Support Wood (1PC)	ALLEN KEY (1PC)
	6 Ø10mm x 40mm
	DOWEL (4PCS)





ASSEMBLY INSTRUCTIONS


DINING CHAIR



WF296299

IMPORTANT NOTE:

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- 2) BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP



	Part List For One			Hardware List For One	
No	Parts Desc.	Q'ty	No	Hardware Desc.	Q'ty
A	BACK FRAME		1	Bolts	2pcs
		⇒ lpc	2	Bolts	4pcs
			3	Spring Washer 5/16"*13mm x 1.5mm	6pcs
В	SEAT FRAME	lno	4	Flat Washer 5/16"*19mm x 1.5mm	6pcs
		lpc	5	Bolts 1/4"*50mm	4pcs
	FRONT LEGS		6	Spring Washer 1/4"*11mm x 1.5mm	4pcs
C		2pcs	7	Flat Washer © 1/4"*16mm x 1.5mm	4pcs
			8	Allen Key 4mm*60mm	1pc

