

## ! SAFETY WARNINGS !

1. This bed is designed for use only mattress(es) meeting the following specifications on the upper bunk, and lower bunk:

Bed Type	Length	Width	Thickness 8" max
Twin Standard	74" - 75"	38 <sup>1</sup> / <sup>2</sup> "	
Full Standard	74" - 75"	53 <sup>1/2</sup> "	8" max

- 2. Replacement parts, including additional guardrails, may be obtained from any of our (GIGACLOUD TECHNOLOGY(USA) INC) dealers
- 3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed.
- 4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
- 5. Surface of the mattress must be at least 5" (127 mm) below the upper edge of guardrails.
- 6. Do not allow children under 6 years of age to use the upper bunk.
- 7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- 8. Do not allow horseplay on or under the bed and prohibit jumping on the bed
- 9. Always use the ladder for entering and leaving the upper bunk.
- 10. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 11. Use of a night light may provided added safety precaution for a child using the upper bunk.
- 12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
- 13. The use of water or sleep flotation mattresses is prohibited.
- 14. STRANGULATION HAZARD Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes.
- 15. Keep these instructions for future reference

PARS LIST & HARDWARE (BOX 1-WF286851) 3					
~~ Note : Do Not Fully Tighten Screws until Fully Assembled ~~					
1	2	3	4		
Upper left leg (front and back) 2pcs	Upper right leg (front and back) 2pcs	Upper side Fame 1pc	Top horizontal bar on the left 1pc		
5	6	10	11		
Upper side panels right 1pcs	Horizontal bar on the top right 1pc	Below legs (left and right) 4pcs	The top horizontal bar of the lower bed 2pcs		
12	15	16	20		
Below side panels 2pcs	Center Legs 2pcs	Stair railing above 1pc	Stair railing above 1pc		
Mid side panel 1pc	31 Stair railing below 1pc				


## PARS LIST (WF286852) ~~ Note : Do Not Fully Tighten Screws until Fully Assembled ~~ 7.1 13 7 9 Upper side rail Lower side rails Longguardrail (Back)-4pcs Verticalguardrail-4pcs (front and back) 2pcs (front and back) 2pcs

١

7

1. Align and fix the Upper left leg (1), and the Upper side fame (3), using the Hexagonal bolts catch wood (A), and the Wood dowel (B), Tighten with Allen Key (P).


2. Align and fix top left bar (4), Using Wood Screws (C), tighten with screw driver (not included)




## STEP 2

1. Align and fix the Upper right leg (2), and the Horizontal bar on the top right (6), using the Hexagonal bolts catch wood (A), the Wood dowel (B), Tighten with Allen Key (P).


2. Align and fix the Upper side panels right (5), using the Hexagonal bolts catch wood (D), the Hex-Head bolts (E) and the Canopy head though (F), Tighten with Allen Key (P).






STEP 4


1. Align and fix the Slats (8), Using Wood Screws (C), tighten with screw driver (not included)







STEP 7

1. Align and fix the center legs (15), and the slats (18), Hex-Head bolts (E), tighten with Allen key(O).



STEP 8
Align and fix the Slats (17&18), Using Wood Screws (C), tighten with screw driver (not included)








1, Align and fix the Board standing below (19), with the Horizontal board below (24), and the Back panel (22).

- 2, Align and fix the Board standing between (14), with the Horizontal board between (25), and the Back panel (22).
- 3, Align and fix the Board standing between (14), with the Horizontal board between (26), and the Back panel (22).
- 4, Align and fix the The board is in the above (21), with the Horizontal board above (25), and the Back panel (22).
- => Using Hex-Head bolts (K), and Wood dowel (L) tighten with Allen Key (P).



STEP 11 Align and fix the Bottom side panel (28), Between side panel (29), Above side panel (30), Using Wood Screws (M), tighten with screw driver (not included)

