



SAFETY WARNINGS




1. This bed is designed for use only mattress(es) meeting the following specifications on the upper bunk: *Upper bunk* (bunk bed and tribed included)


Upper bed

Bed TypeLengthWidthThicknessTwin Standard74"-75"37 1/2"- 38"6" max


- Replacement parts, including additional guardrails, maybe obtained from any of our (GIGACLOUDTECHNOLOGY (USA) INC. 18961 ARENTH AVENUE CITY OF INDUSTRY, CA, 91748) dealers.
- 3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed.
- 4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
- 5. Surface of the mattress must be at least 5". (127 mm) below the upper edge of guardrails.
- 6. Do not allow children under 6 years of age to use the upper bunk.
- 7. Periodically check and ensure that the guardrail, ladder, and other components are in theirproper position, free from damage, and that all connectors are tight.
- 8. Do not allow horseplay on or under the bed and prohibit jumping on the bed
- 9. Always use the ladder for entering and leaving the upper bunk.
- 10. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 11. Use of a night light may provided added safety precaution for a child using the upper bunk.
- 12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to thewall, the guardrail that runs the full length of the bed should be placed against the wall to prevententrapment between the bed and wall.
- 13. The use of water or sleep flotation mattresses is prohibited.
- 14. STRANGULATION HAZARD Never attach or hang items to any part of the bunk bed that are notdesigned for use with the bed; for example, but not limited to, hook, belts and jump ropes.
- 15. Keep these instructions for future reference
- 16. Prohibit more than one person on upper bunk.
- 17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet.
- 18. Be certain all staples are out of the box before beginning assembly on the shipping carton.

Page: 2 of 32







Page:4 of 32



Page: 5 of 32




Page: 6 of 32




Page: 7 of 32


Hardware List (WF298769)


No.	OUTLOOK	DESC	QTY
A		Dowel Ø10*30mm	04
B		Dowel Ø10*40mm	32
<u>(C)</u>	@ Company of the control of the cont	Screws Ø6.5*30mm	04
D	9 - Tolland	Screws Ø6.5*50mm	32
E		Screws Ø6.5*70mm	16
F	0	Bolt s 1/4"*70mm	22
G		Bolt s 1/4"*30mm	08
H		Bolts 1/4"*25mm	04
(I)		Cross dowel 1/4"*13mm	22
K		Screws Ø6.5*30mm	08
M		Bolt s 1/4"*25mm	14
N	(S) paramagan	Flat head screw #8*25mm	28
0		Allen key 60*22*4mm	01








Page: 10 of 32























































Page: 29 of 32



Page: 30 of 32






Assembly for:

Decorative frame on the left side of the tent.

OPTION 2:



Assembly for:

Decorative frame on the right side of the tent.

Page: 31 of 32

OPTION 3:

Assembly for:

Decorative frame on the mid side of the tent.

Page: 32 of 32