
ASSEMBLY INSTRUCTIONS


DINING BENCH




WF293570

IMPORTANT NOTE:


- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- (2) BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE BENCH IS FULLY SET-UP





ASSEMBLY INSTRUCTIONS


DINING CHAIR



WF293570

IMPORTANT NOTE:

- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- (2) BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- (3) DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP



Part List **Hardware List** Ø1/4" x 75mm BOLT (4pcs) Ø1/4" x 55mm SEAT FRAME (1pc) BOLT (4pcs) Ø1/4" x 35mm BOLT (2pcs) LEGS CHAIR (2pcs) Ø1/4" x 13mm SPRING WASHER (10pcs) Ø1/4" x 19mm FLAT WASHER (10pcs) BACK FRAME (1pc) Ø10 x 30mm WOOD (1pc) 4mm

ALLENKEY (1pc)

