



ASSEMBLY INSTRUCTION

WF295369AAB&WF295369AAK







WF295369AAB&WF295369AAK



① x 1	② x 1	③ x 1	④ x 1
⑤ x 1	⑥ x 2	⑦ x 1	⑧ x 1
⑨ x 2	⑩ x 1	⑪ x 1	⑫ x 1
⑬ x 1	⑭ x 4	⑮ x 1	

Φ6x30mm			Φ4x40mm	Φ3x12mm	Φ4x14mm
A x 20+2	B x 12+1	C x 12+1	D x 10+1	E x 6+1	F x 36+3
			Φ3x14mm		M6x40mm
G x 3	H x 8+1	I x 2	J x 8	K x 8+1	Lx4
	Φ4x14mm				
M x 1	N x 18+2	Ox 2	Px 4	Qx 2	


Step 1




Step 2




Step 3




Lx4






Step 4






Step 5







Step 6





Step 7



Step 8




Step 9






x 6

Step 10



Step 11



Step 12

