
ASSEMBLY INSTRUCTIONS

WF295551 - DINING CHAIR

IMPORTANT NOTE:

- ** PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ** BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- **DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP.



CARTONS ONLY ONE/ CARTONS SEULEMENT UN							
PART LISTS				HARDWARE LISTS			
NO.	DESCRIPTION	SKETCH	Q'TY	NO.	DESCRIPTION	SKETCH	Q'TY
1	CHAIR BACK		2 PCS	А	BOLT Ø1/4" x 38mmL	(1)	4 PCS
2	SEAT		2 PCS	В	BOLT Ø1/4" x 50mmL		8 PCS
3	FRONT LEG		4 PCS	С	BOLT Ø1/4" x 75mmL	(1)	8 PCS
				D	SPRING WASHER Ø1/4" x 13mmL		20 PCS
				E	FLAT WASHER Ø1/4" x 19mmL		20 PCS
				F	ALLEN KEY		1 PCS

