
ASSEMBLY INSTRUCCIONES


ITEM NOTE: WF310957

DINING TABLE



IMPORTANT NOTE:

- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OP CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- 2 BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- (3) DO NOT TIGHEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY STEP-UP



Part List For One				Hardware List For One			
No	Parts Desc.		Q'ty	No	Hardware Desc.		Q'ty
Α	TOP PANEL		1pcs	1	Bolts 5/16" x 50mm	(a)	4pcs
				2	Bolts 5/16" x 40mm	@	4pcs
В	LFAF		1pcs	3	Bolts 1/4" x 35mm	(Minimum)	8pcs
С	JOINT PLATE BETWEEN		1pcs	4	Spring Washer 5/16" x 13mm x 1.5mm	ම	8pcs
	LEGS AND TABLETOP			5	Flat Washer 5/16" x 16mm x 1.5mm	0	8pcs
D	LEGS &		4pcs	6	Spring Washer 1/4" x 13mm x 1.5mm	©	8pcs
Е	LEGS		1pcs	7	Flat Washer 1/4" x 16mm x 1.5mm	0	8pcs
				8	Allen Key 4mm*60mm		1pcs
F	MIDDLE STRETCHER		1pcs	9	Wooden Pegs		4pcs

