

## **ASSEMBLY INSTRUCCIONES**

ITEM NOTE: WF310958
DINING CHAIR



## **IMPORTANT NOTE:**

- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OP CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- 2 BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- 3 DO NOT TIGHEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY STEP-UP



Part List For One				Hardware List For One		
No	Parts Desc.	Q'ty	No	Hardware Desc.	Q'ty	
A	BACK FRAME		1	Bolts 1/4" x 35mm	2pcs	
		1pcs	2	Bolts 1/4" x 75mm	4pcs	
В	SEAT FRAME	1pcs	3	Bolts	4pcs	
			4	Bolts 1/4" x 30mm	2pcs	
С	RIGHT ARM		5	Bolts 1/4" x 40mm	2pcs	
		1pcs	6	Spring Washer 1/4" x 13mm x 1.5mm	14pcs	
D	LEFT ARM	1pcs	7	Flat Washer 1/4" x 16mm x 1.5mm	12pcs	
			8	Allen Key 4mm x 60mm	1pcs	
Е	FRONT LEGS	2pcs				

