


For longer use

Re-tighten bolts every 6 months by using

the enclosed allen-key.

*Using an electric drill can damage the chair. Please re-tighten bolts manually.



Safety Information



chair, with your back to

the backrest



edge of the chair



Do not stand on the

chair



Do not use the chair with more than one person

Sit in the center of the Do not sit at the front



Do not push the chair around when a person is sitting in it



Do not push down on the backrest when a person is reclined



Do not place all your weight on only the backrest

INSTRUCTION MANUAL

Model: C-2077 B HJ-Customer-Service@outlook.com **(**909)637-7665 | (909)637-7593





Package List





(1)*1 Seat









(7)*1 Wrench

INSTRUCTION MANUAL **C-2077**

BHJ-Customer-Service@outlook.com (0909)637-7665 | (909)637-7593 EST 9:00AM--17:00PM



Assembly Instruction



CAUTION:

* Before using the chair, check to ensure that all bolts are fully tightened. * Lubricate all parts and tighten all bolts every 6 months or whenever needed.

Seat Height: Paddle-shaped lever on the right side



To raise: While taking your weight off chair, lift lever up.

To lower: While seated, lift lever up.