


ASSEMBLY INSTRUCTIONS




WF305757/WF305758/WF305761/WF305762


Parts List




A




B




C




D




E




F



G




H




I * 16




P * 16




J




K * 2




L * 3



M * 2











N









O

WF305757 BOX 4-1: A+F+D+M+L+I*4+P*4
 WF305758 BOX 4-2: H+C+E+M+L+I*4+P*4
 WF305761 BOX 4-3: J+O+K*2+I*4+P*4
 WF305762 BOX 4-4: G+B+N+L+I*4+P*4

Installation method







After inserting the latch, please turn the back of the sofa upward, and then press firmly on the protruding position of the armrest in the direction of the arrow.

