
















# **ASSEMBLY INSTRUCTIONS**




**WF320124/ WF320135/ WF320136/ WF320137**

# PART LIST


A		1PC	<b>WF320136: AX1 CX1 EX1 FX1 GX1 HX1 IX4 JX8 KX8 MX8 LX1.</b>
B		1PC	
C		1PC	<b>WF320137: BX1 DX1 EX1 FX1 GX1 HX1 IX4 JX8 KX8 MX8.</b>
D		1PC	
E		2PCS	<b>WF320124: NX1 IX4</b>
F		2PCS	
G		2PCS	<b>WF320135: NX1 IX4</b>
H		2PCS	
I		16PCS	
J		16PCS	
K		16PCS	
L		1PC	
M		16PCS	
N		2PCS	

1




IX 2

2




MX 4

3




**M X 4**

4




**I X 2**  
**J X 8**  
**K X 8**  
**L X 1**

5




**F X 1**

6




7




IX 2

8




MX 4

9




**MX 4**

10




**IX 2**  
**JX 8**  
**KX 8**

11




FX 1

12






13




IX 4

14




**15**




**IX 4**


**16**




**17**



**WF320137**




**WF320136**



**18**

**WF320124**



**WF320135**

19

