
ASSEMBLY INSTRUCTION

ITEM #: WF531505

Thank you for purchasing this quality Product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. idenlify and count all parts and compare with the parts list below.

ASSEMBLY INSTRUCTION:



2. Please check to see that all hardware and parts are present prior start of assembly.

3. Please follow attached instruction in the sme sequence as numbered asure fast and aesy assembly.


WARNING!


- Dont attempt to repair or modify parts that are proken or defective. Prease contact the store immediately.
 This productis for home use only and not intended for commercial esatablishments.
 Two persons are required for assembly.
 Approximate assembly time 1/2 hours.
 Component parts and fittings contained in the box. Prease sort out all parts before you begin to assemble the item. This is the make a true you always use the correct part.


item. This is to make sure you always use the correct part.
It is STRONGLY RECOMMENDED that you ANCHOR this product toling furniture can cause serious injuries and death. To prevent your furniture from tipping forward it is strongly recommended that you securely attach this product to a wallr other solid surface, using the anchor straps provided appropriate fixings.


No.	Component		Q'ty
Α		Top frame	1
В		Below frame	1
С	Û	Leg center	1
D		Left side frame	1
Е		Right side frame	1
F		Mid side frame	1
G		Left shelve	1
Н		Right shelve	1
ı		Left door	1
J		Mid door	1
K		Right door	1
L		Front Stretcher	1
М		Stands Stretcher Front	1
N		Backs	1


	No.	Component		Q'ty
	1	O	Bolt Ø 6.3x35 mm	15
	2	0	Spring Washer 6.3x13 mm	15
	3	0	Flat Washer Ø 6.3 x 18 mm	15
	4		Allen Wrench 4 mm	1
	5		Handles	3
	6	<u>-</u>	Bulon Ø4 x 25mm	6
	7		Door hinge	6
	8		Lock the upper door	3
	9		Lower door brake	3
	10		Lock the upper door	3
	11		Lower door brake	3
	12	THE STATE OF THE S	Srews Ø4 x 40 mm	4
	13		Srews Ø4 x 15 mm	30
	14	•	Srews Ø4 x 15 mm	36
	15		Shelf Pins Ø5.8 mm	8
	16	•••	Srews Ø3 x 12 mm	32
	17	0	Wooden pegs Ø 8x30 mm	4
•			not included	











1	O	Bolt Ø 6.3x35 mm	11 Pcs
2	0	Spring Washer 6.3x13 mm	11 Pcs
3	0	Flat Washer Ø 6.3 x 18 mm	11 Pcs
4		Allen Wrench 4 mm	1 Pc

