

PART LIST

A x20	B x8	C x16	D x2	E x2	F x2
G x2	H x14	I x4	Tools		
Extra			Tools		

1 x1	2 x1	
3 x1	4 x1	
5 x1	7 x2	8 x2
6 x2		

01

2 x1	3 x1	
7 x2	A x8	C x8

02

1 x1	6 x2
A x4	B x8

03

4 x1	A x4
C x4	

04

5 x1	A x4
C x4	

05

D x2	E x2	
F x2	G x2	H x14

06

1 x4	8 x2
-------------	-------------