


This Fire Screen has multiple parts and may require up to some 30 minutes to assemble.


To give you an overview of the Fire Screen parts, the above picture is to help you put the various parts into perspective.

Please read through the instructions herebelow to familiarise the parts and steps before assembly.



Caution: To finish this step with your partner.

Attach the Foot(B) to the Screen(A) using Bolt(1) with Allen Key(2). Tighten all Bolts at all joints.



Care & Maintenance	
	Furniture may scratch floors. We recommend using furniture pads to protect your floors.
•	Do not put hot items directly on furniture surface.
⊘ — •	Do not clean furniture with harsh cleansers or polish.
Ø Ö. •	Do not place furniture under direct sunlight.
•	Do not place furniture near heating or cooling vents.
ØL.	Do not write on furniture without a padded barrier to protect the surface.
⊘ ♀	Do not place furniture outside . For indoor use only.
⊘	Not for commercial use. For residential use only.
Ø 🖷 •	Stains may be removed with mild soap solution and damp cloth.
0 🌾 •	Children should not climb or jump on the furniture.
< ✓ <>> •	Dust and pick-up spills using a clean, non-colored, lint-free cloth.