





ASSEMBLY INSTRUCTIONS						
<u>WF321012</u>						
1	Leg		1pc	10	Center rails 4pc	cs
2	Leg		1pc	11	Slats Slats	s
3	,,,,,,,		1pc	12	Center rails legs support	cs
4	Leg		1pc	13	Side rails 2pc	s
5	Foot board frames		2pcs	14	Center leg <u>2pc</u>	cs
6	Headboard panel		1pc	15	Headboard frames	cs
7	Foot board panel		1рс	16	Foot board frames support	С
8	Headboard panel		1pc	17	Headboard leg	cs
9	Side rails		2pcs			
WF321012(Hardware in this SKU)						
A	Ø4x30 (*)⊐\$\$\$\$\$\$\$\$\$	32	PCS	F	6.5x50 ()))))))) 8PCS	
В	1/4×100	10	PCS	G	1/4x25 占 10PCS	5
С	1/4x65	8	PCS	Н	1/4x30 0 12PCS	5
D	Ø10x40	6	PCS	Ι	1/4x35 🔍 2PCS	
E	4x58	1	PC	J	Ø4x25	
					Phillip head screw Not include	
PAGE 3 OF 8						









ASSEMBLY INSTRUCTIONS

