


Noble House Home Furnishings LLC.



Step 4		
Stand the Chair, then your Chair is ready for use. This Chair can only be used on the flat and level surface.		
Care & M	aintenance	
0 🗖 •	Do not put hot items directly on furniture surface.	
Ø 🔒 🔸	Do not clean furniture with harsh cleansers or polish.	
∕♀•	To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.	
Ø 🏌 •	Children should not climb or jump on the furniture.	
0L.	Do not write on furniture without a padded barrier to protect the surface.	
√ 👷 •	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.	
⊘ 📇 •	Not for commercial use. For residential use only.	
ø 🖥 •	Stains may be removed with mild soap solution and damp cloth.	
√ 	Dust and pick-up spills using a clean, non-colored, lint- free cloth.	