
## Assembly Instructions Caution: You must read this before you proceed **Care & Maintenance** Ø Not for commercial use. For residential use only. Furniture may scratch floors. We recommend using furniture pads to protect your floors. Ø Do not put hot items directly on furniture surface. 0 Do not clean furniture with harsh cleansers or polish. $\oslash$ Do not place furniture under direct sunlight. Ø Do not place furniture near heating or cooling vents. Do not write on furniture without a padded barrier to Ø protect the surface. Do not place furniture outside . For indoor use only. $\oslash$ Stains may be removed with mild soap solution and 0 damp cloth. 0 % Children should not climb or jump on the furniture. Dust and pick-up spills using a clean, non-colored, 10 lint-free cloth. Please look in Leg for hardware pack.




## Part List


Label	Picture	Description	QTY
A		Seat with Back	1
В		Front Leg	2
С		Back Leg	2

## <u>Hardware</u>

Label	Picture	Description	QTY
1		Bolt (M8*60MM)	5
2		Bolt (M8*50MM)	5
3		Spring Washer	10
4	6	Washer	10
5		Allen Wrench	1




assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Place the Seat with Back(A) on the side of a table with the Seat facing down, as seen in the picture.

Insert Front Legs(B) into the mounting positions of Seat with Back(A) and attach using Bolts(1), Spring Washers(3) and Washers(4) with the Allen Wrench(5). Insert Back Legs(C) into the mounting positions of Seat with Back(A) and attach using Bolts(2), Spring Washers(3) and Washers(4) with the Allen Wrench(5).

Do not fully tighten the Bolts at this time.



Turn the Chair right side up.Check for stability and then tighten all the remaining bolts.DO NOT fully tighten a bolt in one go and then move on to the next. Rather, in asequential manner, gradually tighten each bolt until all bolts are evenlysecured.This methodology will ensure maximum evenness once all bolts are fullytightened. If the Chair wobbles adjust the Pre-installed Levellers at the bottom of the Legs until the Chair is level. Your Chair is ready for use.

This Chair can only be used on a flat, level surface.