

Operating Instructions

Caution : You must read this before you proceed




SAFETY WARNING

Never adjust chaise lounge or recliner backrest while seated.

Always make sure the backrest is flat before moving the chaise lounge.

Keep all limbs clear from under the backrest when it is in a raised position.

Serious finger, hand, or other bodily injuries may result from adjusting the chaise lounge backrest position while seated.



The examples pictured above are non exhaustive and are for your reference only

Care & Maintenance



- Not for commercial use. For residential use only.



- Prolonged exposure to rain may cause rusting which can stain floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Stains may be removed with mild soap solution and damp cloth.



- Keep away from sources of ignition.




- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Operating Instructions

Caution : You must read this before you proceed



Lounger



CAUTION : This Lounger is NOT a TOY.
Keep your child/children at bay when opening or folding the Lounger.

Operating Instructions

Step 1







Position the Lounger as pictured.

To open: Unfold the Leg Frames as indicated by the arrows.

Then stand the Lounger up.

This process is best performed with an adult helper.

Step 2








Lift up the Backrest and fold down the Support.

Place the Support into the lock at your desired Backrest height.

Your Lounger is ready for use.

This Lounger can only be used on a flat, level surface.

Step 3



To close: Lift the Backrest Support out of the lock and fold it back up as pictured.
Fold the Leg Frames back into the base of the Lounger.