



Parts List				
Label	Picture	Description	QTY	
A		Table Top	2	
В		First Leg	2	
С		Second Leg	2	
D		First Support Bar	2	
E		Second Support Bar	3	
F		Third Support Bar	2	

Hardware				
Label	Picture	Description	QTY	
1		Bolt (M6x60mm)	9	
2		Bolt (M6x35mm)	9	
3	<i><a>aaaaaaaaaa</i>	Screw (M6x55mm)	21	
4		Screw (M6x40mm)	17	
5		Allen Wrench	2	


Assembly Preparation


Before Beginning Assembly:








To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




















Step 6.2:		
Then insert a Screw ((4)) using the Allen Wrench ((5)) as shown in picture above. Only loosely tighten the screws at this time.		







With assistance from your adult partners, turn the Table back to normal position on a flat ground.

EXERT pressure, floorwards, onto the Table.

This pressure will help the Legs and Table Top reach alignment at all joints. Check for wobbles on a LEVEL surface. If the table does not wobble, then proceed to tighten all the bolts and screws.

When tightening these screws and Bolts, tighten sequentially.

DO NOT tighten any screw or bolt fully and then move towards the next one. This would cause the frame to warp.

If there are any wobbles after tightening, loosen the screws and bolts and execute this same process.

Inspect the Table and make sure all parts are adequately connected. Your Table is ready for use.

This Table can only be used on a flat, level surface.

Care & Maintenance:				
	•	Do not put hot items directly on furniture surface.		
	•	Do not clean furniture with harsh cleansers or polish.		
√ Ö	٠	To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.		
0 🟋	•	Children should not climb or jump on the furniture.		
0 L	•	Do not write on furniture without a padded barrier to protect the surface.		
√ 0	•	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.		
0	•	Not for commercial use. For residential use only.		
	•	Stains may be removed with mild soap solution and damp cloth.		
	•	Dust and pick-up spills using a clean, non-colored, lint- free cloth.		