
## **Assembly Instructions**

## ARMCHAIR

CAUTION: You must read this before you proceed.

Please look in the Leg Panel for hardware packs





**CAUTION :** This ArmChair is NOT a TOY. Keep your child / children at bay in the process of assembly.


For turning / flipping the armchair and to prevent damage to the armchair, 02 persons may be needed to execute this action.


Noble House Home Furnishings LLC

Parts List			
No.	Picture	Description	Qty
А		Backrest Panel	1
В		Left Arm Panel	1
С		Right Arm Panel	1
D		Seat Panel	1
Е		Seat Cushion	1
Hardware			
No.	Picture	Description	Qty
		Long Screw (M8x90mm)	5
2		Short Screw (M6x80mm)	5
3		Allen Wrench	1
Assembly Preparation			
Before Beginning Assembly:			
A B C D A X5			
Read instructions, cover to cover.			
<b>Å</b> <sub>2X</sub>	Have 2 adults on hand for assembly.		
	Do not assemble on flooring or carpet.		
	Assemble on a clean non-marring surface (packing foam).		
	Save all packaging until finished.		
Noble House Home Furnishings LLC			2 OF 7









## Care & Maintenance

0 Do not put hot items directly on furniture surface. 0 Do not clean furniture with harsh cleansers or polish. To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended. Children should not climb or jump on the furniture. Do not write on furniture without a padded barrier to protect the surface. To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings. Not for commercial use. For residential use only. Ø Stains may be removed with mild soap solution and damp cloth. Dust and pick-up spills using a clean, non-colored, lint-free cloth.