






Assembly Instructions




W68766568








Box 1/1:


- (1) (2) (3) (4) (5) X2 (6) (7) (8) X2 (9) (10) (11) (12)
- (13) X2 (14) X2 (15) X2 (16) X2 (17) X2 (18) (19)

A × 65  M4x8mm	B × 8 	C × 1 	D × 4  M4x22mm
E × 4 	F × 8 	G × 2 	
H × 4  M3x8mm M3 T=3mm Ø3	I × 10 	(13) × 2 	
(14) × 2 	(15) × 2 		

1







A x 7
M4x8mm





3

A x2
M4x8mm



4

A x 4



M4x8mm



H x 4





M3

T=3mm




Ø3



5

B × 8






6

D × 4






M4x22mm



7

A x 34
M4x8mm

E x 4















8

A x 2



M4x8mm

G x 2



9

