ASSEMBLY INSTRUCTIONS




CLUB CHAIR WITH CUSHIONS*




SCAN FOR ASSEMBLY VIDEO AND ONLINE INSTRUCTION MANUAL

This Club Chair includes the following:

1 Club Chair





2 Cushions W/Covers





CLUB CHAIR ASSEMBLY PARTS


PART	DESCRIPTION	IMAGE	QUANTITY
SB	Seat Board		1
FP	Front Panel		1
ВР	Back Panel		1
LP	Left Arm Panel		1
RP	Right Arm Panel		1
FT-31	Foot		1
FT-32	Foot		1
FT-33	Foot		1
FT-34	Foot		1














4







Caution!: Please assemble "Front" and "Back" as the pic shown.
Incorrect assembly could result in damaging of product!





5





6







Please note that it may take up to 24 hours for the cushions to reach their final firmness.




Care & Maintenance








Children should not climb or jump on the furniture.





- Not for commercial use. For residential use only.
- Stains may be removed with mild soap solution and damp cloth.
- ✓ Keep away from sources of ignition.

