







Care & Maintenance	
0 555	Do not put hot items directly on furniture surface
•	Do not clean furniture with harsh cleansers or polish.
0 Ö. •	To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.
\circ $()$	Children should not climb or jump on the furniture.
•	Do not write on furniture without a padded barrier to protect the surface.
 ○ ○ • • • • • • 	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
	Not for commercial use. For residential use only .
	Stains may be removed with mild soap solution and damp cloth.
<i>.</i>	Dust and pick-up spills using a clean, non-colored, lint-free cloth.