

Assembly Instructions

		Caution : You must read this before you proceed	
Care & Maintenance			
0		 Not for commercial use. For residential use only. 	
0		 Prolonged exposure to rain may cause rusting which can stain floors. 	
0		 Do not put hot items directly on furniture surface. 	
0	Creaver	 Do not clean furniture with harsh cleansers or polish. 	
\checkmark	Ö	 To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended. 	
0	×	 Children should not climb or jump on the furniture. 	
0	L	 Do not write on furniture without a padded barrier to protect the surface. 	
v	<u>م</u>	 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings. 	
0	le la	 Stains may be removed with mild soap solution and damp cloth. 	
1		 Keep away from sources of ignition. 	
1		 Dust and pick-up spills using a clean, non-colored, lint-free cloth. 	



<u>Step 2</u>



Adjust the adjustable tube of the back, to find the suitable height. Your Lounge is ready for use.

This Lounge can only be used on a flat, level surface.



