


ASSEMBLY INSTRUCTIONS

ITEM#HHSB22002




If you find any damage after opening, please be sure to take pictures of the damage and contact us. We will help you solve the problem as soon as possible.


THANK YOU

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




- VI. Insert cam lock into panel tighter with a screwdriver;
Note: Please don't over-tighten the cam lock, otherwise, it will be broken.




- VII. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal
by screw adjustment




In-and-Out
by loosening the hinge-arm
mounting screw or via cam
adjustment

























Vertical
Via slots in the mounting
plate or via cam adjustment

Parts List



Hardware List

1		Ø8x30	Wooden dowel	20 pcs
2		Ø6x32	Cam bolt	14 pcs
3		Ø15x9.5	Cam lock	14 pcs
4			Sticker	14 pcs
5			Europe hinge	8 pcs
6		Ø4x12	Screw	48 pcs
7		Ø4x18	Screw	8 pcs
8			Handle	4 pcs
9		Ø3x12	Screw	4 pcs
10			Plastic wedge	12 pcs
11		Ø3x17	Screw	12 pcs
12			Shelf support pin	8 pcs
13			Hexagon socket key	1 pc
14		Ø6x38	Screw	6 pcs
15		M6x10	bolt	32 pcs
16			Connector	16 pcs
17-1		Ø4x16	Screw	2 pcs
17-2		Ø4x25	Screw	2 pcs
17-3			Plastic strap	2 pcs
17-4			Nut	2 pcs
18			Glue tube	1 pc




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1


2:  6 pcs





Step 2




1:  8 pcs

2:  4 pcs




Step 3

- 1:  12 pcs
2:  4 pcs





Step 4

- 3:  4 pcs




Step 5

3:  4 pcs




Step 6

3:  6 pcs





Step 7






Step 8




13:  1 pc

14:  6 pcs








Step 9

9:		4 pcs
10:		12 pcs
11:		12 pcs





Step 10

- | | | |
|-----|---|--------|
| 13: |  | 1 pc |
| 15: |  | 16 pcs |
| 16: |  | 16 pcs |







Step 12

- 13:  1 pc
15:  16 pcs








Step 14

- 4:  16 pcs
- 12:  8 pcs




Step 15

5:		8 pcs
6:		16 pcs
7:		8 pcs
8:		4 pcs




Step 16

6:  16 pcs









Step 17

6:  16 pcs




Step 18

17:		2 pcs
:		2 pcs
:		2 pcs
:		2 pcs




WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



Step 19



Final Assembly