



Leading the Way in Safe Box Manufacturing Excellence!



01	PRODUCT STRUCTURE
02	FIRST-TIME OPENING
03	BATTERY INSTALLATION
04	SETTING THE PASSWORD
05	OPENING THE GUN CABINET
06	ALARM SYSTEM & SILENT MODE
07	CUSTOMER SUPPORT AND WARRANTY

Thank you for choosing our products. Please take time to read and familiarize yourself with the proper operating procedures presented on the following pages.

**IMPORTANT NOTE:**

- 1.The cabinet can be tipped over by children or adults, please make sure the cabinet is mounted on the wall or floor. Keep the keys in a secure place away from children.
  - 2.Do not move the gun cabinet with the door open; make sure the door is closed before moving the gun cabinet.
  - 3.Do not storing firearms with loaded ammunition in this product. If you encounter any issues or challenges while using the gun cabinet, please feel free to contact us, and we will respond promptly. Many problems can be quickly resolved without the need for a return.
- Our customer support team is available to answer any questions and assist with any issues you may encounter.


# PRODUCT STRUCTURE



# PARTS LIST



Gun Cabinet\*1



Instruction Manual\*1



Emergency Cable\*1



Expansion Screws\*4



Emergency Key\*2

## FIRST-TIME OPENING



**STEP 1:** Remove the magnetic keyhole cover.

**STEP 2:** Fully insert your key into keyhole, turn it counter-clockwise to the limit.




**STEP 3:** Rotate the knob clockwise to open the door.

**NOTICE:** The LED inside the gun cabinet will not light up when the key is used to unlock it.

## BATTERY INSTALLATION

**STEP 1:** After opening the door, locate the battery compartment on the backside of the door panel ;

**STEP 2:** Prepare four brand new AA batteries and insert them into the battery compartment, ensuring to observe the correct polarity.



Interior  
Battery  
Compartment



## IMPORTANT NOTE:

- 1.Rechargeable battery is not recommended as it may destroy the internal electronic components of the gun cabinet
- 2.Please use brand-new batteries, do not mix used batteries with new batteries.
- 3.LOW BATTERY ALERT: If 5 short beeps sound while using the gun cabinet, the batteries are dying. Replace the batteries as soon as possible.

## SETTING THE PASSWORD

### IMPORTANT NOTE:

- 1.Do not lock the emergency key inside the gun cabinet.
- 2.The initial password of the gun cabinet is "1234", please change it according to your personal needs. No fingerprint is valid until the fingerprint is set.
- 3.If the gun cabinet is not used for a long period of time, the batteries should be removed to prevent liquid leakage from damaging the electronic system.
- 4.After pressing the button for 20 seconds, the gun cabinet will go into hibernation if there is no subsequent operation.
- 5.Please purchase 4 AA batteries in advance, batteries are not included in this gun cabinet.

## SETTING THE PASSWORD

**STEP 1:** Open the cabinet and press the setting button, the indicator light flashes green and a short beep sounds.

**STEP 2:** Input your password (4-10 digits) and press setting button again.

**STEP 3:** With a long beep, the password is set successfully. When the light turns off, you can use the code to unlock the cabinet.



## SETTING THE FINGERPRINT:


**STEP 1:** Open the cabinet and press the setting button, the indicator light flashes green and a short beep sounds.

**STEP 2:** Place the fingerprint to be enrolled on the fingerprint sensor and hear a "beep". Remove your finger and repeat the process three times.

**STEP 3:** When the fingerprint is successfully enrolled, the green light will flash twice with a "beep, beep" sound.

### NOTE:

1. A maximum of 24 fingerprints can be registered.
2. Press and hold the setting button for more than 5 seconds, with the beep and the indicator green light flashing, the setting will be cleared and the password (fingerprint) will be reset to "1234". Then please follow steps 1~3 to set a new password (fingerprint).



## OPENING THE GUN CABINET

### THREE UNLOCKING METHODS:

1. The first unlocking method: Using the emergency key ;

Insert the emergency key into the keyhole, turn it counterclockwise to the limit. Then turn the handle to open the gun cabinet door (Suitable for unlocking or for the first opening, forgetting the password, or when the battery is dead);

2. The second unlocking method: Using the keypad password (fingerprint) ;

After installing the battery, input the password (fingerprint), the cabinet will be successfully unlocked with a beep and indicator light flashing green. Then turn the handle to open the gun cabinet door;

3. The third unlocking method: Using the emergency cable + password(fingerprint).

When the battery is too low to open the door, please use the emergency cable and connect the gun cabinet and charging power or charging head, then enter the correct password (fingerprint) to open the door.

## ALARM SYSTEM & SILENT MODE

### ALARM SYSTEM:

After 5 consecutive incorrect code entries, the gun cabinet will activate the alarm system and the alarm will sound for 60 seconds, then enter the correct code and the alarm will be canceled.

### SILENT MODE:

1. Press and hold the "1" key for more than 3 seconds, the indicator light flashes without any beeps. Mute mode is successfully activated.
2. Then press and hold the "1" key for more than 3 seconds to turn off the mute

## CUSTOMER SUPPORT AND WARRANTY

We offer 2 years warranty and lifetime key service. If your key is lost or damaged, please provide us with your Amazon order ID, shipping address and the serial number on the safe's lock cylinder via post-sale email, website or WhatsApp, and we will have a replacement key ready for you as soon as possible.

**NOTE:** If the key is lost or damaged due to personal reasons, we will cover the cost of the replacement key. However, you need to bear the shipping cost. Thank you for your understanding. If you have any questions or issues, we encourage you to contact us at

# Dear Customer

Thank You for Choosing

I hope this letter finds you well. On behalf of , I would like to express our sincere gratitude for choosing our gun cabinet to protect your valuable possessions. We truly appreciate your trust in our products and services.

At , we strive to provide the highest quality gun cabinet that combine state-of-the-art security features with exceptional craftsmanship. It is customers like you who inspire us to continually improve and innovate in our pursuit of excellence.

We value your satisfaction and would love to hear about your experience with our gun cabinet. Your feedback is essential in helping us understand your needs better and enhance our offerings to meet your expectations. We kindly request a few moments of your time to provide us with your valuable insights through the attached feedback form. Your input will be treated with the utmost care and confidentiality.

Should you have any questions, concerns, or require any assistance with your safe or any of our other products, please do not hesitate to contact our dedicated customer service team . We are always here to assist you in any way we can.

Once again, we thank you for choosing . We value your business and look forward to serving you in the future.

Yours sincerely,

customer service center