








ASSEMBLY INSTRUCTIONS

ITEM NO: 8041

Accent Chair

| | | |
|---|--|--|
| <p>A*1 BODY</p>  |  <p>1</p> | |
| <p>B*2 FRONT LEG</p>  |  <p>2</p>  <p>3</p> <p>Back leg should kick out towards the back after assembly</p> | |
| <p>C*2 BACK LEG</p>  | | |
| <p>D*4 WASHER</p>  | | |

Note : Please Tighten Firm But Do Not Over Tighten Legs