


# Assembly Instructions

**Caution : You must read this before you proceed**

## Chair



## Parts List


Label	Picture	Description	QTY
A	A line drawing showing the upper part of the chair, including the seat and the backrest. It has three small circles on the backrest and two on the seat.	Chair	1
B	A line drawing of the chair's base, showing four legs and a central support structure that connects the legs.	Chair Base	1

# Hardware

Label	Picture	Description	QTY
①		Bolt (M8*55mm)	5
②		Allen Key	1
③		Washer	5
④		Spring Washer	5

# Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


# Assembly Steps

## Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

## Step 1



With assistance from your adult partners, Turn the Chair(A) face down on a clean, non-marring surface as shown in picture.

## Step 2



Attach Chair Base(B) onto the bottom of the Chair(A) using Bolts(①), Spring Washers(④), Washers(③) with Allen Key(②).


Note: The 2 shorter legs and 2 longer legs should be at the right direction as pictured above.

When tightening the Bolts, tighten sequentially.

DO NOT tighten any Bolt fully and then move towards the next one.

This could cause the other Bolts and mounting points to be out of alignment.

## Step 3



Ensure that all the Bolts are not fully driven in.

Stand the Chair right side up and ensure it is stable.

Place the Chair on a level Surface to check if it wobbles.






If it wobbles, it's very likely that the Chair Base is not fixed perfectly. Please remove the Chair Base Bolts and make a little adjustment. Then reattach.

If no wobbles are found, proceed to tighten all the Bolts.

Your Chair is ready for use.

**Caution: This Chair can only be used on a flat, level surface.**

## Care & Maintenance

-  Do not put hot items directly on furniture surface
  -  Do not clean furniture with harsh cleansers or polish.
  -  Do not place furniture under direct sunlight.
  -  Do not place furniture near heating or cooling vents.
  -  Do not write on furniture without a padded barrier to protect the surface.
  -  Do not place furniture outside . For indoor use only .
  -  Not for commercial use. For residential use only .
  -  Stains may be removed with mild soap solution and damp cloth.
  -  Children should not climb or jump on the furniture.
- 
-  Dust and pick-up spills using a clean, non-colored, lint-free cloth .