
# **Curio Cabinet**







Estimated time for assembly:

## 80 mins



Weight limitations are as follows:






Assemble the furniture on an empty carton, carpet, or rug to prevent scratches or damage.

For safety, please keep pets and children away from the assembly area.

Ensure the product is fully assembled before use. If you are missing any hardware or products, do not use it until you have restored the missing parts.



This furniture requires 2 people for assembly.

Read this instruction manual prior to assembly to familiarize yourself with the various steps.

Lay out all components and hardware separately on a flat surface and make sure that no parts are missing or damaged before assembly. Do not destroy or discard any packaging until you are certain that you have all the necessary parts for assembly.


Hand tight all hardwares and careful not to over tighten to avoid damaging the product.

#### CAUTION

There are small components used in the construction of this product. Loose items should be kept away from pets and children to avoid a choking hazard.

Keep all plastic bags and packaging film away from pets and children to avoid suffocation.


### **PACKAGE CONTENTS**




### **PACKAGE CONTENTS**

CODE	DESCRIPTION	QTY
1	Upper Shelf Top Panel	1
2	Upper Shelf Bottom Panel	1
3	Lower Shelf Top Panel	1
4	Base	1
5	Left Panel	2
6	Right Panel	2
7	Vertical Support Bar	2
8	Back Panel	4
9	Mirror Back Panel	4
10	Glass Cabinet Door	2
11	Glass Shorage Shelf Panel	4


### **PACKAGE CONTENTS**







Install all hardware perpendicular to the opening.




1x

2x

2x

2x

#### Required tools for assembly (Not included)



1


Attach magnetic catch to the underside of the upper shelf top panel (1).









(G) 4x



Attach the cabinet light socket to the underside of the upper shelf top panel (1).









Assemble the left panel (5), right panel (6), and vertical support bar (7) on top

3







of the upper shelf bottom panel (2).


9

Assemble the upper shelf top panel (1) on top of the upper shelf assembly.








5




Attach the mirror back panels (9) and the back panels (8) to the back of the upper shelf assembly. Attach anti-tipping straps to the top of the shelf.
















Attach magnetic catch to the underside of the lower shelf top panel (3).



Assemble the lower shelf top panel (3) on top of the lower shelf assembly.







9




Attach the mirror back panels (9) and the back panels (8) to the back of the lower shelf assembly.



Assemble the upper shelf on top of the lower shelf.







Insert shelf pegs into the cabinet.



(K) 20x





 $\underline{\wedge}$  Caution when handling glass panels.

Attach magnetic metal plates to the corner of the glass cabinet doors (10). Insert cabinet door pivot hinges to the cabinet and slide the glass cabinet doors into the hinges.




(H) 2x



1 2x




(J) 2x



 $oxed{\boxtimes}$  Caution when handling glass panels.

Adjust the position of the glass cabinet doors. Make sure they are not slanted and the doors can properly operate without hitting other parts.










2x






Affix the cabinet to the wall.



Furniture must permanently fixed to the wall stud with included anti-tipping device to prevent the furniture from tipping over.

- Mark the drill position on the wall with a pencil.
- Drill a small hole on the marked position.
- Insert a wall anchor into the drilled hole.
- Fixed the anti-tipping strap to the wall with provided screws.

## YOU'RE FINISHED!




#### Warning

Only place items on top of the product if they meet the recommended size and weight limits.

Climbing on, stepping on, or placing overweighted objects on the product may cause property damage and/or injuries.

Items placed onto this product must be resting on a support surface without hanging over the edges.



#### Warning

Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with included anti-tipping device in order to prevent the furniture from tipping over.

Different wall materials requires different types of wall anchors or screws. Use a suitable wall anchors or screws for your specific wall in order to secure the stability and load bearing capacity of the furniture. If you are uncertain about which type of device to use, please contact us or your local hardware store.