
Assembly Instructions

TABLE

CAUTION: You must read this before you proceed.

Please look in the Leg for hardware packs



CAUTION: This Table is NOT a TOY.

Keep your child / children at bay in the process of assembly.

For turning the table and to prevent damage to the table 02 persons may be needed to execute this action

Parts List				
Label	Picture	Description	Qty	
Α		Table Top	1	
В		1st Legs	2	
С	2 2 3	2nd Legs	2	
D		3rd Legs	2	
E	(· · · · · · · · · · · · · · · · · · ·	Side Support Bar	2	
F		Middle Support Bars	2	
Noble House Home Furnishings LLC 2 OF 10				


Hardware

Table Hardware

Label	Picture	Description	Qty
1		Bolt (M6 x 20mm)	21
2	0	Washers (M6/16 x 2mm)	45
3		Screws (M6 x 30mm)	25
4		Allen Key	1

Assembly Preparation

Before Beginning Assembly:





 \boxtimes Read instructions, cover to cover.







 $\ oxed{oxed}$ Do not assemble on flooring or carpet.








This Table has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the table, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise the parts and steps before assembly.




Unpack and place all parts on a clean, non-marring surface.

Step 2

Step 2.1




Step 2.2




With the help from your partner


- 2.1: Place the Table Top (A) on one side as picture above. Slightly open the table top as the arrow.
- 2.2: Place the Table Top (A) with its underside skywards onto a clean, soft surface to avoid any scratches or damages to the product.



Place Middle Support Bar (F) to the housings of Table Top (A), secure by using the Screw (3), Washers(2) and Allen key (4), as shown in the picture. **Do not fully tighten the Screws.**




Place Side Support Bar (E) to the housings of Table Top (A), secure by using the Screws (3), Washers (2) and Allen Key (4), as shown in the picture. **Do not fully tighten the Screws.**




Place the 2nd Leg (C) to the long side of Table Top (A) and Support Bar (E), secure by using the Bolts (1), Washers (2) and Allen Key (4) as shown in the picture. **Do not fully tighten the Bolts.**

Note: the hinges on 2nd Leg (C) should face inside




Place the 3rd Leg (D) to the long side of Table Top (A) and Support Bar (E), secure by using the Bolts (1), Washers (2) and Allen Key (4) as shown in the picture. Do not fully tighten the Bolts.

Note: the hinges on 2nd Leg (C) should face inside




Repeat the same process in step 5 and step 6 with the other 2nd Leg (C) and 3rd Leg (D) **Do not fully tighten the Bolts.**






Attach the 1st Legs (B) to the short side of Table Top (A) using Screw (③) with Washers (②) and Allen Key (④), as show in picture above.

Do not fully tighten the Screws.



Attach the 1st Legs (B) to the 3rd Legs (D) and 2nd Legs (C) using Bolts (1) with Washers (2) and Allen Key (4), as show in picture above. Do not fully tighten the Bolts.



With assistance from your adult parners, Turn the Table right side up.

Inspect it and make sure all parts are adequately connected.

Check to ensure there is NO WOBBLINESS.

In a sequential manner, ensure all bolts and screws are fully locked into position and secured.

CAUTION: When tightening these screws and bolts, tighten sequentially.

DO NOT tighten any screw and bolt fully and then towards the next one. This would cause the frame to warp.

If there is still wobbles, loosen the screws and bolt and execute this same drop tests. WARNING!! IF TABLE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Ensure all screws and bolts are fully locked into position.

The Table is ready to be used.

Caution: This Table can only be used on flat, level surface.

Care & Maintenance



 Prolonged exposure to rain may cause rusting which can stain floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



 To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



• Children should not climb or jump on the furniture.



• Do not write on furniture without a padded barrier to protect the surface.



To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Not for commercial use. For residential use only.



• Stains may be removed with mild soap solution and damp cloth..



Dust and pick-up spills using a clean, non-colored, lint-free cloth.