


Bluetooth Music Massage Rocking Chair with LED Light

Important Notes


1. Please read this instruction manual carefully before using the product.
2. It is intended for indoor use only and should not be exposed to direct sunlight, moist or extreme environments.
3. The installation and placement process should be done under adult supervision.
4. Children under 12 years old should not use this product alone.
5. Do not use this product on hardwood floors to prevent scratches.
6. Excessive volume adjustment may damage hearing or cause hearing loss.
7. Do not wash or soak this product.
8. If it gets wet, disconnect the power immediately and stop using it until it is completely dry.
9. To avoid injury or electric shock, do not disassemble this product, including the control panel or product cover, without proper authorization.
10. When folding and opening the rocking chair, please do not place hands in the back fold to avoid getting pinched.

Installation and Placement

1. Open and fold the rocking chair, take the rocking chair out of the packaging box, place it on a hard and flat surface, and ensure that the control panel end of the rocking chair is stable and in contact with the ground.
2. Ensure that hands or other objects are kept away from the back fold area of the rocking chair to open it to its extended state.
3. The back fold of the rocking chair has a nylon buckle that can be bonded to fix the extended state of the rocking chair.
4. Before re-folding the rocking chair, please tear off the nylon buckle.



Instructions for Use



1. Find the <Power Connector> near the <Control Panel> and connect it to the household power supply through the <Power Transformer> provided with this product.
2. Press the <POWER> button to turn on the LED light and the rocking chair.
3. Use your electronic device, such as a mobile phone or tablet computer, to search for the Bluetooth name <Ta-pieh Mountain> to connect to the Bluetooth speaker of this product.
4. Press the <M1> button to switch on/off the massage function of the rocking chair base, and press <M2> to switch on/off the massage function of the rocking chair backrest.
5. Press the <MODE> button to select different strength levels for the rocking chair massage function, with three levels:<Low - Medium - High>
6. The rocking chair massage function will automatically turn off after 30 minutes to avoid wasting power or other accidents.
7. The rocking chair provides two charging ports, <USB1> and <USB2>, to solve your battery power concern during the use of electronic products.

Troubleshooting

Q: The Bluetooth speaker does not have volume

- A:**
1. Check if the household power is on and if the <Power Transformer> interface is securely connected.
 2. Check if the power indicator light of the <POWER> button is on.
 3. Check if your electronic device is already connected to the Bluetooth name <Ta-pieh Mountain>.
 4. Check if your electronic device can play sound normally.

Q: The massage function does not work

- A:**
1. Check if the household power is on and if the <Power Transformer> interface is securely connected.
 2. Check if the power indicator light of the <POWER> button is on.
 3. Check if the <M1> or <M2> indicator light is on.

Caution: Please read this instruction manual carefully and pay attention to the surrounding environment before using the rocking chair to avoid collisions, damage, and even personal injury. Ensure that there are no obstacles or foreign objects in the vicinity of the rocking chair to avoid getting caught and injured.