
Assembly Instructions

Caution: You must read this Assembly Instructions before you proceed

Please look in Foldable Seat And Backrest for hardware packs

ROCKING ADIRONDACK




CAUTION: This Rocking Adirondack is NOT a TOY. Keep your child/ children at bay during the assemble process. For moving the Rocking Adirondack and to prevent damage to the Rocking Adirondack, two adults are needed to execute this action.

Parts List				
Label	Picture	Description	QTY	
Α		Right Armrest	1	
В		Left Armrest	1	
С		Foldable Seat And Backrest	1	
D		Support Corners	2	

Parts List				
Label	Picture	Description	QTY	
1		Bolt (M6x35 mm)	3	
2		Sleeve Nut (M6x13mm)	3	
3		Screw (M6x60mm)	3	
4		Screw (M4x30mm) (Use with screwdriver)	5	
5	0	Plastic Washer (Ø6.5/Ø18x2mm)	3	
6		Allen Wrench	2	
7		Screwdriver	Not provided	

Assembly Preparation

Before Beginning Assembly:





- Read instructions, cover to cover-
- Pzx T
- Have 2 adults on hand for assembly-




- Do not assemble on flooring or carpet-
- <u>F</u>
- Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-


Assembly Steps



This Rocking Adirondack has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Rocking Adirondack parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Unpack and place all parts on a clean, non-marring surface.




Insert Wooden Dowel on Support Corners (D) into hole on the leg of Foldable Seat and Backrest (C) then secure using Screws (4) and Screwdriver (7) as above picture.


Repeat the same process with the other Support Corners (D).

Do not fully tighten the Screws.






Turn over Rocking Adirondack and open Backrest as indicated with the arrow.



Put tenon of Backrest Support of Foldable Seat and Backrest (C) into the hole of Right Armrest (A) using Screw (③), Allen Wrench (⑥). Attach Right Armrest (A) to Foldable Seat and Backrest (C) using Bolt (①), Sleeve Nut (②), Plastic Washer (⑤) and 2 Allen Wrench (⑥). Repeat the same process with the Left Armrest (B).


Do not fully tighten the Bolts and Screws.



In a sequential manner, tighten all Bolts and Screws at all joints until fully locked into position.

Your Rocking Adirondack is ready for use.

This Rocking Adirondack can only be used on a flat, level surface.



This Rocking Adirondack can be folded shut.

To fold this Rocking Adirondack, raise up Backrest and fold Seat with Leg Frame as indicated by the arrows, by hand, until the Rocking Adirondack folds shut.

To open this Rocking Adirondack, open Backrest and Seat as indicated by the arrows, by hand until the Adirondack folds out and locks into position.

Note: This Rocking Adirondack is slightly heavy, do exercise caution to avoid injury.

Care & Maintenance



Do not put hot items directly on furniture surface





Do not clean furniture with harsh cleansers or polish.



To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



Do not write on furniture without a padded barrier to protect the surface.



To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Not for commercial use. For residential use only .



Stains may be removed with mild soap solution and damp cloth.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.