




















<p>1</p>  <p>1028*406 1 PCS</p>	<p>2</p>  <p>581*388 1 PCS</p>	<p>3</p>  <p>400*388 1 PCS</p>	<p>4</p>  <p>140*388 1 PCS</p>	<p>5</p>  <p>798*388 1 PCS</p>
<p>6</p>  <p>124*368 1 PCS</p>	<p>7</p>  <p>798*388 1 PCS</p>	<p>8</p>  <p>400*368 1 PCS</p>	<p>9</p>  <p>400*60 2 PCS</p>	<p>10</p>  <p>590*134 1 PCS</p>
<p>11</p>  <p>733*409 1 PCS</p>	<p>12</p>  <p>600*430 1 PCS</p>	<p>13</p>  <p>430*138 1 PCS</p>	<p>14</p>  <p>430*138 1 PCS</p>	<p>15</p>  <p>300*90 2 PCS</p>
<p>16</p>  <p>300*90 2 PCS</p>	<p>17</p>  <p>345*90 2 PCS</p>	<p>18</p>  <p>355*294 2 PCS</p>		




Hardware installation demonstration

NOTE: Please make sure "A" hardware tightened and can't be pulled out!


I



II



III













IV




Scan QR code for assembly video






1



	A*8	put A on board ①
	C*16	put C on board ②③⑧⑨

②






	A*14
	C*10
	F*2
	G*2
	K*8

put A on board ④⑤⑥⑦

put C on board ④⑤⑥⑦

3




Make sure the arrow on the screw align to the hole on the side.



B*12 put B on board ③⑧⑨

4



Make sure the arrow on the screw align to the hole on the side.





B*2

put B on board ②




D*4

5








Make sure the arrow on the screw align to the hole on the side.







B*8






put B on board ④⑤⑥⑦







6








	J*18
	K*4
	R*18
	V*1

7









	E*2
	K*4
	N*2
	O*2
	P*1
	Q*2


8




put A on board 13 14



	A*8
	K*8
	L*4
	P*2
	Q*4
	S*1

9








Make sure the arrow on the screw align to the hole on the side.








	B*8
	M*8


put B on board 15 16

10



	H*2
	I*2
	K*8
	T*1
	U*2

11



---END---